

# The Synthetic Grass Warehouse

Australia's No 1 Supplier for Artificial Grass & Accessories

## DIY Installation Guide

1

### PREPARE THE BASE

Layout the proposed area. Excavate the area to a depth of 80mm or required suitable depth to existing sub base. Lay 80mm of crushed rock/roadbase and compact with vibrating plate. The level of crushed rock/roadbase when compacted should be 15-20mm below "finished height" of surrounding edging/paving.



2

### TRIM TO SIZE

Lay your artificial grass, making sure you start from one edge and roll out. Cut the over-hanging quantities with a sharp Stanley Knife. Remove the "salvage", black strip from both sides of the grass. This **cannot** be used to join the grass.



3

### GLUE TOGETHER SEAMS

When joining rolls of grass together, be sure to use the Joining Tape along the seams. Using a 4mm notched trowel, apply Outdoor Adhesive evenly along the Joining Tape as you go. Remember to pressure roll the seams once the grass has been joined to promote good adhesion.



4

### SECURE IN PLACE

Once you have covered the complete area, simply nail all of the perimeters down at 500mm intervals using 150mm flat head nails or Turf Pegs as indicated.



5

### GROOM YOUR GRASS

Top dress the grass with an even sprinkling of fine, washed and dried silica sand to a depth of 15-20mm. A broom can be used at this stage to sweep in the sand evenly and to also brush the grass blades straight and vertical.



#### ATTENTION:

- Do not attempt to lift the grass by yourself. It is advised the rolls be cut into manageable lengths before shifting.
- Always run grass in one direction.
- Ask for our product specification sheet for help to work out required amount of infill.

*The installation information has been supplied as a reference guide. No representations or warranties are made regarding the installation information.*